


Wi-Fi 6E Smart Mesh System

User Manual

PORTS and BUTTONS



* Ethernet (Internet) cable from your Internet Service Provider or modem should be plugged into WAN ethernet port of Air 4980 / Air 4985 device.

Please remove the protective plastic on the products before installation.


INSTALLATION

To install the Airties Wireless devices, please download “Airties Vision” application on your mobile device by scanning this QR code. Please follow the instructions in the mobile application to complete your setup.



TIPS FOR BEST PERFORMANCE

- Keep devices away from:
 - Potential sources of electrical interference. Equipment that may potentially cause interference include home security systems, microwaves and consumer electronic devices.
 - Large metal surfaces and objects.
 - Sources and areas of heat such as ovens and sun rooms as well as direct sun light.
- Please make sure to remove the protective plastic on the device before first use.
- Please use the device in upright position. The openings are provided for ventilation, do not block or cover openings.
- Your device is designed to work indoors and under room temperature conditions only. Avoid placing the device to very cold, very hot, very humid or very dry locations inside your home.
- To change advanced settings on your device, you can access web UI with the credentials below by typing <http://masternode.local> in the address field of your browser and press enter to display the login window:
 - Username: admin
 - Password: default Wi-Fi password on the label under your device.



RETURNING TO FACTORY SETTINGS



To return the device to factory settings, press down on the reset button (in the small opening on the back shown above) for 5 seconds and release. A metal paperclip (with an extended tip) or strong toothpick are typically good choices for this task. When the reset process is triggered, the LED in the front will “blink rapidly” and the device will reboot to factory settings.

PRODUCT NOTICES

- Operational modes:
 - 2.4 GHz:** 802.11b, 802.11g, 802.11n (HT20), 802.11n (HT40), 802.11ax (HE20), 802.11ax (HE40)
 - 5 GHz:** 802.11a, 802.11n (HT20), 802.11n (HT40), 802.11ac (VHT20), 802.11ac (VHT40), 802.11ac (VHT80), 802.11ac (VHT160), 802.11ax (HE20), 802.11ax (HE40), 802.11ax (HE80), 802.11ax (HE160)
 - 6 GHz:** 802.11ax (HE20), 802.11ax (HE40), 802.11ax (HE80), 802.11ax (HE160)

TROUBLESHOOTING

Condition	LED Color	LED Behavior	Timing	Explanation	Recommended Action(s)
Power OFF	OFF	-		Device is turned off.	Make sure the power button on the back is pressed and power supply unit is connected to the device.
Power ON, booting	White	Blinking			No action required. If the device was just powered on, please wait for at least 2 minutes for the device to boot up.
Wireless network healthy	Green	Blinking	50 milliseconds OFF 5 seconds ON	LED is steady green with a short blink every 5 seconds.	No action required.
Device configured as single wireless access point	Green	Solid		Device is connected to the router/gateway with an ethernet cable and acts as a wireless access point. No other mesh devices are configured in the network.	No action required, more mesh devices can be added to the wireless mesh network if needed.
Unconfigured mesh device	Blue	Blinking	4 seconds OFF 4 seconds ON	Device is not configured and connected to the wireless mesh network.	Configure the device using Airties Vision app.
Weak connection to the wireless mesh network	Red	Solid			Bring device closer to another device in the wireless mesh network.
No Internet	Red	Blinking	1/2 second OFF 1/2 second ON	Your internet connection is down.	Please check WAN ethernet cable connection between your modem and Air 4980, Air 4985 device. If the issue persists, contact your Internet Service Provider.
Software upgrade	Blue	Blinking	1/2 second OFF 1/2 second ON	Device is retrieving the latest software.	Wait for the upgrade to complete. Device will automatically start with the latest software.